



lily floating fountain

floating solar powered fountain

operates in direct sunlight



If you have any problems, please contact Smart Solar before returning to the place of purchase. For immediate answers visit our website www.smartsolar.com where you will find an extensive trouble shooting section with frequently asked questions and instant email enquiry forms.

usa

tel : +1 877 550 8840

email : ussupport@smartsolar.com

uk

tel : +44 (0) 8456 441 833

email : uksupport@smartsolar.com

germany

tel : +49 (0)151 12744268

email : servicede@smartsolar.com

smart solar ltd, gelderse weg 53, D-46399 Bocholt

europa

email : eusupport@smartsolar.com

australia

tel : +61 03 9512 0680

email : service@aspenwood.com.au

asia/ pan pacific

email : service@tgs.co.th

www.smartsolar.com



Contents

1. Introduction
2. Before you start
3. Overview
4. Components
5. Assembling and using your product
6. Cleaning and maintenance
7. Trouble shooting
8. Spare parts
9. Full 2 year warranty

Introduction

Thank you for purchasing a Lily Floating Fountain. These instructions contain important information for using this product. Please keep them in a safe place for future reference.

Before you start

The Lily Floating Fountain can be used in a pond or water reservoir provided the solar panel receives direct sunlight. A solar panel powers the pump by converting sunlight into electricity.


The solar panel will power the pump when exposed to direct sunlight. If the sun passes behind a cloud then the amount of electricity produced by the panel will decrease and the pump will stop working or slow down. As soon as the sun reappears from behind the cloud the amount of electricity will increase instantly and the pump will begin to work again.

The amount of electricity produced by the solar panel is proportional to the strength of sunlight received. For optimum performance we recommend that your solar panel should be exposed to as much direct sunlight as possible and away from shady areas e.g. under trees.

Overview

The Lily Floating Fountain has been designed for outdoor use. The pump drives water up through the fountain head and then sprinkles down into the pond. The water is constantly re-cycled.

Components



- | | |
|---------------------|-------------------|
| 1 Solar module | 2 Pump |
| 3 Resin Lily Frame | 4 Float |
| 5 Fountain head set | 6 Anchor sack set |

Assembling and Using Your Product

Unpack all components carefully. Please ensure that you check all parts have been removed from the packaging.




First attach the pump to the tube on the bottom of the solar module. Do not use force.

Choose your favourite fountain head and insert it into the tube on the solar module.

The Lily Floating Fountain is now ready to use.

In order to prevent the Lily Floating Fountain from floating into the shade, you may use the anchor sack set to anchor it.

Please note: On first use there may be air in the pump. It can take up to 5 minutes until all the air is expelled and water begins to sprinkle through the fountain head.



Fountain head & Anchor sack set



Attach pump to the tube



Weigh down the anchor sack using stones

Cleaning and Maintenance

Pump: If after time the pump starts to lose power or stops working you should check for the build up of sediment or scale in the bottom of the pump housing. Carefully take out the lily and turn it upside down on a soft surface. Dry the solar pump connector and disconnect.

Remove the pump from the plastic unit and open the pump cover at its base. Remove the impeller and remove any dirt or scale which has built up. Replace the impeller and replace the pump cover.

IMPORTANT

To ensure the seal remains water-tight twist the pump and panels connectors together rather than merely pressing them together. Check that the small rubber "o" ring remains in its' groove and is not pushed out when connecting. If this ring moves there will be no water seal and the pump and panel will eventually fail.

Solar panel: The panel should be cleaned periodically with a soft tissue and proprietary glass cleaning solution. Regular cleaning of the panel is advised to maintain optimum conversion of the sun's energy into direct current.

Trouble Shooting

If you have any problems please contact Smart Solar before returning to the place of purchase. For immediate answers visit our website www.smartsolar.com where you will find an extensive trouble shooting section with frequently asked questions and instant email enquiry forms.

Pump does not operate even though the solar panel is in full sunlight


- 1) Check the connection of the pump to the solar panel. If loose then re-connect, rotating the connectors until good contact is made. If any of the cabling is damaged then seek a replacement.
- 2) Check whether the impeller is blocked by removing the pump cover. If it is, then clean the pump as detailed above.

Pump does operate but there is no water running through the tube


- 1) Check for the build up of sediment, scale or dirt in the filter and in the bottom of the pump housing as detailed above.
- 2) Check whether the pump cover is attached properly. If the pump cover is not pushed down tightly, the pump will not push water through the fountain head.



Turn upside down on a soft surface and remove the pump unit



Ensure the underwater connector is water tight.



impeller pump cover



Remove pump cover



Take out impeller to clean

Please note:

In winter the Lily Floating Fountain must be stored in a dry and frost proof environment.

The pump must never be operated dry (out of water) as this will have a permanent adverse affect on the performance of the pump.

Spare parts

1. Solar panel	2060AS01
2. Resin Lily Frame	2440LILY
3. Pump	20020P01
4. Pump impeller	IMPELLER
5. Pump cover with filter	PCOVER
5. Fountain head set	2440FH

Full 2 year warranty

If within 24 months from the date of purchase this product fails due to a defect in material or workmanship, Smart Solar will replace or repair free of charge.

Please report immediately if there is any damage or missing pieces upon receipt of goods.

The warranty does not apply to:

Damage caused by accidents, abuse, poor handling, frost or normal wear and tear. Products which have been subject to unauthorized repair or modification.

For further information please contact your nearest customer service centre detailed on the last page of this manual.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.



Smart Solar reserve the right to modify any product to enhance its' performance and design.